

■ **CLASS DISCUSSION ITEM 8.3**

***Laboratory A/D Conversion***

Why is a 12-bit A/D converter satisfactory for most laboratory measurements?